



We must make sure that our sub-contractors properly protect the floor at all times:



Photo of oil from a pipe cutter – this will create a problem with the floor underlayment and the final floor covering adhering properly.

Many sweep compounds have oil or wax which might affect the bond of the flooring mastic or floor leveling product.

We have found a product which does not contain these components,

"Kleen Sweep"

We need to make sure that ALL floor compounds sweep come from our yard,

This includes our sub contractors. Do not purchase at your local home center.

Please make sure that this is discussed at your Pre-Install meetings with all the subs.



Make sure that the floor is protected with masonite, plywood, or as a last resort, double cardboard. Making sure that the protection is large enough to fully protect the floor from splatter is very important. Make sure that the protection is cleaned daily.

