



When installing bond breaker tape, be careful **NOT to stretch the tape**, and make sure the surface is **clean and smooth** for tape installation!



When stretched, the tape will de-bond and create weak points in the joint. It is difficult not to stretch the tape during install...care must be taken. *It is always better to have enough material removed for a backer rod installation when possible... These areas will need to be cut out and re-installed.*



Also, as discussed before, make sure that the **correct width** tape is installed and allow sufficient time for out-gassing of any ground material underneath!  
*Call the Quality Department if you have questions.*