

Exposed End Dams

We must verify that the end dams are concealed
(Review shape of sill prior to installation...
Also, flashing should not be cut flush with the masonry edge.



End Dams should be placed **UNDER** the main flashing run



Mastic should not be used as an end dam.

Mastic is only for the seams. Verify it's use with other products that come in contact...such as AVB, ETA, Etc.

End Dams need only to be 2" in height and held back $\frac{1}{2}$ " - $\frac{3}{4}$ " from the front face of the masonry wall.

